

Refill Instructions

Lexmark No.82 (18L0032)

Lexmark: Z55, Z55se, Z65, Z65n, Z65p, X5100, X5130, X5150, X5190, X6150, X6170, X6190 Pro. Dell: 740, 940, 960.



1. Enlarge the filling hole sufficiently to accept the steel filling tube using the screw provided. **IMPORTANT: DO NOT REMOVE TOP.**
2. Fill syringe with ink, insert the steel filling tube into the filling hole and push downwards into the centre of the sponge.
3. **SLOWLY** inject ink, when the ink overflows from filling hole cartridge is full. Stop injecting ink immediately. **DO NOT** reseal filling hole.
IMPORTANT: Clean syringe with water and dry.
4. Leave cartridge to stand overnight on a protective, non-absorbent surface, this will ensure no leakage and give the ink time to fully saturate the sponge.
IMPORTANT: DO NOT LEAVE ON TISSUE.
5. Install cartridge and run a priming cycle. (When installing the cartridge the printer may ask if the cartridge is a **NEW** or **OLD** cartridge. click on **NEW** to reset the printer).
IMPORTANT: For best results, refill whilst ink still remains in cartridge. Empty cartridges should be refilled immediately.

