

# Refill Instructions - Lexmark No.41 (18Y0141)

Lexmark

Multi-Function                      X4850, X6570, X7550  
Inkjet                                      Z1520

## Items Required

Original Lexmark No.41 Cartridge,  
Drill, Syringe, Filling Tube, Newspaper, sticky tape & Colour Ink



1. Lay down some newspaper in the area you are refilling to protect the surface you are working on.
2. Remove the label from the top of the cartridge. (fig.1)
3. You will see that there are 3 very small holes on the top of the cartridge, see fig.2 for accurate positions.
4. These holes need to be enlarged to allow the steel filling tube access. Use the drill to enlarge the three holes.

Note : On some cartridges you will not find any holes. If you have this cartridge you will have to drill the holes in the positions indicated in fig.2

5. To prevent contamination cover the 2 holes you aren't filling with tape.
6. Fill the syringe with 7ml of the required ink.
7. **SLOWLY** refill the cartridge. Make sure you are putting the correct ink in the correct hole (fig.2)
8. Repeat as necessary, making sure to cover the other 2 holes each time to prevent contamination.
9. When finished remove all tape and insert into printer.
10. Leave the cartridge to stand for around 8 hours. This will allow the ink to fully saturate the sponge inside the cartridge.
11. Run 1-3 cleaning cycles and then your printer cartridge should be ready to use.

The cartridge should now print like a new cartridge, although the ink level monitor will show it as empty. The ink monitor does not reset.



fig.1




fig.2